

USB CHARGER

Kurzanleitung | Quick Guide



TECHNISCHE DATEN

EINGANG	USB PORT
LADESTROM	bis zu 1.600 mA

1. Zuerst den USB CHARGER mit dem Lupine Akku verbinden.
2. Anschließend den USB CHARGER mit dem USB Port verbinden.

● **Bereit oder voll** ● **Ladevorgang**

Achtung! Der USB CHARGER kann mit dem USB Port verbunden bleiben. Allerdings sollte der USB CHARGER vom Akku getrennt werden, wenn dieser nicht mehr über USB geladen wird.

TECHNICAL DATA

INPUT	USB PORT
CHARGING CURRENT	up to 1.600 mA

1. First connect the USB CHARGER with the Lupine battery.
2. Then connect the USB CHARGER with the USB Port.

● **Ready or full** ● **Charging**

Attention! You can leave the USB CHARGER connected to the USB Port. However if you disconnect it from the USB Port, also disconnect it from the battery itself.

LUPINE LIGHTING SYSTEMS GMBH


Im Zwiesel 9, 92318 Neumarkt, Germany

Telefon: +49 (0) 9181 509 49-0

E-Mail: info@lupinelights.com

www.lupinelights.com

Weiterentwicklungen unserer Produkte und technische Änderungen vorbehalten.



@lupinelights
@lupinelights_professional



@Lupine
@Lupine Professional



@Lupine Lights